

GROUND STRAP TESTER

Model 252C



Operating Instructions

4/09



electro-tech systems, inc.

www.electrotechsystems.com

3101 Mt. Carmel Avenue, Glenside, PA 19038 • Tel: (215) 887-2196 • Fax: (215) 887-0131

1.0 APPLICATIONS

The Model 252C Ground Strap Tester shown in Figure 1.0-1 is a precision wall or bench mounted test instrument that can test virtually all types of personnel grounding cable/wrist strap and heel strap assemblies. The instrument measures ESD grounding straps with a nominal resistance of 1 MegOhm. It can be used to test a strap assembly alone or a complete cable/wrist strap system while on the wrist of the user. The grounded power supply used in the Model 252C enables heel straps attached to personnel to be tested without any additional connections when used in conjunction with grounded floor systems (RTG 10^5 Ohms).



Figure 1.0-1: Model 252C Ground Strap Tester

2.0 EQUIPMENT DESCRIPTION

The Model 252C Ground Strap Tester is housed in a heavy-duty plastic housing measuring 4.75" x 4.75" x 2" (121x121x51mm). The removable top cover is attached to the base unit by four captive screws. A silicon rubber gasket provides additional protection from outside contamination. The system is AC powered and incorporates a built-in transformer coupled regulated power supply protected by a ¼ amp fuse. Either 115 or 230VAC operation can be specified. A heavy-duty 3-wire, 18 gauge, 8 foot long power cord is provided.

3.0 SET-UP

The Model 252C is designed to be permanently mounted to a wall, but also may be mounted to a workbench or be free standing. The unit contains four mounting holes that will accept up to a #8 (4mm) size screw (not supplied unless a specific type is specified and ordered separately) The type of screw and its length will depend upon the surface to which the unit is mounted. For wood walls, a 3/4" (20mm) long wood screw is recommended. For plaster or dry wall, either a toggle bolt or a plastic anchor should be used. For concrete walls, a plastic or lead anchor is recommended.

The hole pattern required is shown in Figure 3.0-1. It is recommended that the holes in the base unit be used to locate the actual location of the holes.

To gain access to the mounting holes remove the front cover by unscrewing the four captive screws. Carefully lift the cover and if necessary, disconnect the ribbon cable from the selector switch PC Board.

CAUTION:
Disconnect the power cord whenever the front cover is removed.
115 or 240 VAC INSIDE.

Locate the mounting holes on the wall using the base as a template and then mount the Model 253A using the appropriate screws.

Reconnect the ribbon cables. The connector is polarized. It can only fit into the mating connector one way. The notch on the connector locks into a groove on the plastic overhang of the PCB connector as shown in Figure 3.0-2.




Figure 3.0-1: Location of mounting holes



Figure 3.0-2: Interconnect cables

Carefully replace the front cover. Make certain that the interconnect cable does not interfere with the pushbutton. When tightening the captive screws, apply equal torque. Do not over tighten since this will distort the rubber gasket.

4.0 OPERATION

4.1 Testing cable and wrist strap only

- a. Place STRAP SELECT Switch in the STRAP ONLY position.
- b. Connect the grounding end of the cable to the appropriate mating banana jack or snap located on the front of the unit. If the strap has a clip connection, attach the clip to one of the snaps.
- c. Touch the main grounding point on the strap to the Push-To-Test Button and then depress the button.
- d. If the cable/wrist strap assembly resistance is between the specified limits (assembly good), the Red FAIL Light will flash and the beeper will sound momentarily, then the Green PASS LED will light continuously indicating the strap is good.
- e. If the assembly resistance is below (shorted or low resistance) or above (high resistance or broken resistor, wire or connection) the specified limits, the Red FAIL light will continue to flash on and off and the beeper will continue to sound indicating a defective cable/wrist strap assembly.
- f. The cable or wrist strap portion of the assembly that contains the limiting resistor can be tested separately by following the procedure in “a” to “e” above.

4.2 Testing cable/wrist assembly on wearer’s wrist

- a. Place the STRAP SELECT Switch in the STRAP & WEARER position.
- b. Connect the grounding end of the cable to the appropriate mating banana jack or snap located on the front of the unit. If clip connection is used, attach the clip to one of the snaps. Attach the strap to the wrist in a normal manner.
- c. Depress the PUSH TO TEST button and observe the PASS/FAIL indicators.
- d. If the total system resistance (cable/strap/wearer) is within the specified limits (system good), the Red FAIL light will flash and the beeper will sound momentarily, then the Green PASS LED will light continuously, indicating that the Cable/Strap/Wearer system is good.
- e. If the total system resistance is below (shorted resistor) or above (broken resistor and/or wire, open connection or poor contact between the strap and wearer) the specified limits, the Red FAIL light will continue to flash on and off and the beeper will continue to sound, indicating a defective cable/strap/wearer system.
- f. If the cable/strap/wearer system fails, check the cable/strap assembly alone as described in Section 4.1 above. If the cable/strap assembly checks good, the problem is poor contact resistance between the wearer and the wrist strap assembly. The wearer may have to apply a lotion to the skin to improve contact.

NOTE: It is recommended that the cable/strap assembly be tested alone (Section 4.1 above) even if the cable/strap/wearer system tests good.

4.3 Using the Ground Strap Tester as a grounding point

- a. Plug the ground strap into the appropriate STRAP INPUT connector. The strap is now grounded through the third wire ground in the power cord.
- b. Select the appropriate STRAP & WEARER function (ESD or ORDNANCE).
- c. Periodically depress the PUSH TO TEST Button to check the integrity of the cable/strap/wearer resistance.
- d. If a FAIL indicator is activated, test the cable and/or strap as per Section 4.1 above.

4.4 Testing heel straps and conductive footwear

- a. Place the STRAP SELECT selector switch in the FOOTWEAR position.
- b. If the facility is equipped with a grounded conductive floor (RTG 10^5 Ohms), simply depress the PUSH TO TEST Button to test the effectiveness of the footwear grounding system.
- c. If the location does not have a conductive floor, then a metal plate (ETS Pt#5771, 12"x12" [305x305mm]) that the user must stand on to test the footwear is connected to the STRAP INPUT 0.162" (4mm) banana jack located at the bottom of the unit next to the power cord as shown in Figure 4.4-1.



Figure 4.4-1: Ground plate connection

5.0 AUTOMATIC FUNCTIONS

5.1 System Self-Test

The Model 252C contains a FAIL-SAFE measurement system that checks the Tester each time the TEST BUTTON is depressed. The Red FAIL indicator MUST ALWAYS FLASH (at least for an instant) each time the Test Button is pushed even if the cable and wrist strap being tested is good. Should the Ground Strap Tester fail to give this indication (even if it shows a PASS indication) a malfunction in the Tester should be suspected. DO NOT USE the Ground Strap Tester unless it is functioning as described herein. If in doubt, contact Electro-Tech systems, Inc. at 215-887-2196 so that repairs, if required, can be made.

6.0 SERVICE

The Model 253A Ground Strap Tester contains no user serviceable parts except the ¼ amp 3AG fuse. The fuse should be replaced ONLY WITH AN IDENTICAL

¼ amp 3AG type. If the new fuse also blows, return the complete unit to ETS for repair.

A repair authorization must first be obtained from ETS prior to returning the instrument for service.

7.0 CALIBRATION

The Model 252C calibration may easily be checked by the user by connecting standard 1% resistors, whose values are listed below, between the input connector and the pushbutton.

SWITCH POSITION	MUST FAIL	MUST PASS
Lower Limit –: Wrist Strap and Footwear (Nominal is 750K ± 5%)	<712.5K	>787.5K
Upper Limit – Strap Only: (Nominal is 1.25M ± 5%)	>1.3125M	<1.1875M
Upper Limit – Strap + Wearer: (Nominal is 10M ± 5%)	>10.5M	<9.5M
Upper Limit – Footwear: (Nominal is 100M ± 10%)	>110M	<90M

(The above specifications are calculated. Tolerance on resistors used in ETS test fixtures is 1%)

If the unit does not meet specification, it should be returned to Electro-Tech Systems for repair or recalibration.

Custom units with other resistance limits can be tested by selecting 1% resistors whose values are within 3% of either side of the nominal limits specified.

4/09

8.0 WARRANTY

Electro-Tech Systems, Inc. warrants its equipment, accessories and parts of its manufacture to be and remain free from defects in material and workmanship for a period of one (1) year from date of invoice. It will, at its discretion, either replace or repair without charge, F.O.B. Glenside, similar equipment or a similar part to replace any equipment or part of its manufacture which, within the above stated time, is proved to have been defective at the time it was sold. All equipment claimed defective must be returned properly identified to the Seller (or presented to one of its agents for inspection). This warranty only applies to equipment operated in accordance with Seller's operating instructions.

Seller's warranty with respect to those parts of the equipment that are purchased from other manufacturers shall be subject only to that manufacturer's warranty.

The Seller's liability hereunder is expressly limited to repairing or replacing any parts of the equipment manufactured by the manufacturer and found to have been defective. The Seller shall not be liable for damage resulting or claimed to result from any cause whatsoever.

This warranty becomes null and void should the equipment, or any part thereof, be abused or modified by the customer or if used in any application other than that for which it was intended. This warranty to replace or repair is the only warranty, either expressed or implied or provided by law and is in lieu of all other warranties. The Seller denies any other promise, guarantee or warranty with respect to the equipment or accessories. In particular, as to its or their suitability for the purposes of the buyer or its or their performance, either quantitatively or qualitatively or as to the products that it may produce and the buyer is expected to expressly waive rights to any warranty other than that stated herein.

ETS must be notified before any equipment is returned for repair. ETS will issue an RMA (Return Material Authorization) number for return of equipment.

Equipment should be shipped prepaid and insured in the original packaging. If the original packaging is not available, the equipment must be packed in a sufficiently large box (or boxes if applicable) of double wall construction with substantial packing around all sides. The RMA number, description of the problem along with the contact name and telephone number must be included in formal paperwork and enclosed with the instrument. Round trip freight and related charges are the owner's responsibility.